

“TRANSDUCER” software installation user manual

“TRANSDUCER” software is supplied on a compact disk. To install the software, run the program Setup_Transducer.exe. During installation, the user must specify the directory for the program and some other installation parameters. By default, the directory for hosting the program is: C:\Program Files\Transducer for 32-bit Windows or C:\Program Files (x86)\Transducer for 64-bit Windows.

The installation program overwrites the delivery files in the specified directories, creates the necessary registry keys and creates icons for launching the program.

USB Decoders (T35, T25, T45, T48) Drivers Installation Manual

The drivers for USB decoders are installed during the installation of the “TRANSDUCER” program. In the dialog window “USB drivers installation”, specify the types of decoders with a USB interface that will be used. If these decoders are connected at the time of installation, the drivers for them will be installed immediately. Otherwise, the drivers will be registered in the operating system and installed when the device is connected to the PC.

The drivers can be reinstalled using the USB_Install_Win32.exe program for 32-bit Windows or USB_Install_Win64.exe for 64-bit Windows. One of them will be located in the installation directory of the “TRANSDUCER” program.